



Restore USB Procedure

Overview

The LaunchPad system ships with a USB restore drive which can be used to recover the system in the event of an issue with the Windows operating system.

Note: If you have more than one cable connected to the system's graphics card, please unplug these and leave only the cable for the user monitor.

PLEASE NOTE: WHERE POSSIBLE, PLEASE BACKUP THE LAUNCHPAD CONTENT FOLDERS AND ANY FILES YOU WISH TO PRESERVE. RESTORING ALL PARTITIONS WILL ERASE ALL DATA!

IF POSSIBLE, TRY TO USE ACRONIS "Backup, Files and Folders" TO HAVE A BACKUP COPY OF CONTENT FOLDER. See separate document for directions.

Step 1)


Insert the USB drive into the front USB port of the LaunchPad computer

Step 2)

Press the power button


Step 3)

As soon as the Bios manufacturer logo is seen, access the Boot Option Menu by pressing F11 during bootup.
Select the "UEFI" Option for the USB Drive.




Step 4)

Under the option, What would you like to do? Select “Recover” / “My Disks”




Step 5)

Select the “Browse” button, and open the USB drive [Normally labeled “Removable Drive”]




Step 6)

Open the folder "Image"




Step 7)

Find your restore file.
[Uses the file extension “.tib”]



Step 8)



Select recovery method, "Recover whole disks and partitions"



Step 9)

If you want to PRESERVE the CONTENT, Only select C: Partition.

If you want a FULL RESTORE (You will LOOSE ALL CONTENT), click the Blue Square next to "Disk 1" to automatically select all the sub item boxes.



Step 10)

From here you can click NEXT through the final steps.

The restore process will take approximately 20 minutes.

Once complete, REMOVE the USB Restore drive and boot normally.